

FYS2150

Lab Report: Drag

Nicholas Karlsen

April 26, 2018

Abstract

A study on the flow of an assortment of spheres in a fluid and the use of image processing to determine the terminal velocity.

1 Introduction

2 Theory

3 Experimental Procedure

3.1 Video capture

This report contains the description and analysis of data collected in the lab 21.03.2018 concerning the flow of several spherical objects in a large range of different sizes and densities. The balls were immersed in fluid, dropped and filmed. Post-lab, the raw footage was then processed using a Python script in order to quantify the motion of the spheres. This




Figure 1: Signal used to determine the FPS of the camera

In order to capture the motion of the balls, a USB video camera was connected to a

computer running uEye cockpit [1], which we used to change the settings of the camera and make recordings.

First, the error of the stated FPS of the camera had to be determined. This was done by connecting a series of circular LEDs (see Fig. 1) to a signal generator. The light emitted would "circle" at a rate which could be changed using the signal generator. By adjusting the signal such that the emitted light would seem stationary when observed through the video feed in uEye cockpit, the FPS of the camera determined to be




Figure 3: Most of the balls used in the experiment, excluding the ones labeled small 1 and 2.

4 Results

Type	Mass [g]	Diameter [mm]	FPS	T [°C]	Filename
Metal	502.76	48.98	100	22.7	A1.avi
Metal	28.13	19.02	100	22.8	A2.avi
Metal	6.99	11.97	100	22.6	A3.avi
Metal	2.08	7.99	100	22.6	A4.avi
Metal	0.68	5.48	100	22.5	A5.avi
Metal	0.10	2.98	100	22.6	A6.avi
Plastic	488.41	99.4	100	22.5	B1.avi
Plastic	61.56	50.02	100	22.5	B2.avi
Plastic	7.12	23.89	100	22.6	B3.avi
Plastic	0.87	12.06	100	22.6	B4.avi
White	29.74	25.24	100	22.6	C1.avi
BigB lack	31.42	21.08	100	22.5	C4.avi
Small Black	5.67	16.45	100	22.5	C5.avi
Big Green	31.60	21.86	100	22.4	C3.avi
Small Green	5.60	16.38	100	22.3	C6.avi
Big Red	18.44	24.01	100	22.3	C2.avi
Glass	0.27	5.81	100	22.3	C7.avi
Small 2	12.0E-3	1.59	100	23.7	D2.avi
Small 1	4.1E-3	1.0	100	23.7	D1.avi

Table 1: Spheres

5 Discussion

6 Conclusion

References

- [1] DS Imaging Development Systems GmbH. ueye cockpit.

*

A Code

Following

scripts/lesVideo_conv.py

```
1 #!/usr/bin/env python
2 # -*- coding: utf-8 -*-
3 '''
4 Reads video file and converts to binary image
5 resulting in easy data analysis.
6 author: Nicholas Karlsen
7
8 Note: skvideo is not included in anaconda python,
9 install by 'pip install sk-video' in terminal.
10 '''
11
12 import numpy as np
13 import skvideo.io
14 import inspect
15 import os
16 import matplotlib.pyplot as plt
17 import scipy.constants
18 from skimage.measure import regionprops
19 from matplotlib.image import imread
20 from skimage import util
21 import FYS2150lib as fys # Used for linfit
22 # import skimage.color
23 # from PIL import Image
24 # import skimage.morphology as morph
25 # from skimage import filters
26
27
28 def rgb2gray(rgb):
29     '''
30     Converts shape=(N,M,rgb) array to (N, M) grayscale array see wiki page
31     '''
32     return np.dot(rgb[..., :3], [0.299, 0.587, 0.114]).astype(int)
33
34
35 def gray2binary(gray, limBW=128):
36     """Converts grayscale image to binary grayscale of 0 OR 255
37     image must be array of shape=(N, M)
38     gray: (N, M) array
39     limBW:
40     """
41     bw = np.asarray(gray).copy()
42     bw[bw < limBW] = 0 # Black
43     bw[bw >= limBW] = 255 # White
44     return bw
45
```

```

46 def genFilter(image):
47     """
48     Generates an array to filter out
49     static background based on first frame
50
51     NOT YET IMPLEMENTED
52     """
53     gsImage = rgb2gray(image)
54     bwImage = gray2binary(gsImage)
55     bwImage = bwImage / 255.0
56     return bwImage.astype(int)
57
58 def trackCircle(filename="litenmetallkule.avi", path="current",
59                 hMin=0, hMax=-1, wMin=0, wMax=-1):
60     """
61     Takes video file as input, filters out static background based on
62     first frame and finds the CM of circle in every frame. Requires
63     circle to be only object in frame (after filtering), so requires static
64     background. If not, try adjust hMin, hMax, wMin, wMax to crop out
65     moving
66     background.
67     filename: filename of video
68     path: FULL path of file, eg '/home/nick/Videos/fys2150drag'.
69           if left as default, it will assume same path as script.
70     hMin, hMax, wMin, wMax: used for cropping the image.
71     """
72     # Fetching current dir path
73     folderPath = os.path.dirname(
74         os.path.abspath(
75             inspect.getfile(
76                 inspect.currentframe()))))
77
78     # If path is specified, use that instead.
79     if path != "current":
80         folderPath = path
81         "if path is specified"
82
83     fullFilename = folderPath + "/" + filename
84
85     print "Reading video ..."
86
87     video = skvideo.io.vread(fullFilename)
88     totalFrames = len(video)
89
90     print "Number of frames:", len(video)
91
92     frameStart = 0
93     frameStop = totalFrames
94
95     "Creates array to store x, y vals of CM"
96     cmPos = np.zeros([frameStop - frameStart, 2])
97

```

```

98     validFrames = [] # Keeps track of usable frames
99
100 def detectCirc(image):
101     """
102     Inverts color of image and detects center of circle shape.
103     Assumes circle is the ONLY object in image, so noise
104     needs to be filtered out
105     """
106     #staticBg = genFilter(video[0])
107
108     invFrame = image
109     bwFrame = gray2binary(
110         rgb2gray(
111             util.invert(invFrame)))[hMin:hMax, wMin:wMax]
112     bwFrame = bwFrame # * staticBg
113     # Detects shapes in image
114     props = regionprops(label_image=bwFrame.astype(int))
115
116     return props, invFrame, bwFrame
117
118 for frame in xrange(totalFrames):
119     """
120     Need to invert image for regionprops to work, only finds white obj
121     on black background, not black on white.
122     """
123     # convert to binary grayscale to filter out noise
124     props = detectCirc(video[frame])[0]
125
126     # Bad way of checking if the ball is in frame
127     if len(props) == 0:
128         cmPos[frame] = "nan"
129     else:
130         cmPos[frame] = props[0].centroid # Detects centroids
131         validFrames.append(frame) # Keeps track of frames with ball
132
133     # Print info to terminal while processing
134     print "frame", frame, \
135           "_", "Center of mass:", \
136           "x=%i, y=%i" % (cmPos[frame][1], cmPos[frame][0])
137
138 def plot_im(frame=int(totalFrames / 2.0)):
139     "plot frame + CM, used to check functionality"
140     im = video[frame]
141     props, invFrame, bwFrame = detectCirc(im)
142     cmPos[frame] = props[0].centroid
143     plt.subplot(311)
144     plt.imshow(invFrame)
145     plt.title("Raw image, frame:%i" % frame)
146     plt.plot(cmPos[frame, 1], cmPos[frame, 0] + hMin,
147             "ro", label="Center of mass")
148     plt.legend()
149     plt.subplot(312)
150     plt.imshow(bwFrame, cmap=plt.get_cmap('gray'))

```

```

151         plt.plot(cmPos[frame, 1], cmPos[frame, 0],
152                  "ro", label="Center of mass")
153         plt.title("Processed image, frame:%i" % frame)
154         plt.savefig("figs/graphs/%s_1.png"%vids[row][: -4])
155         plt.legend()
156         plt.show()
157     plot_im()
158
159     return cmPos.astype(int), validFrames
160
161
162 def testFunc():
163     """
164     Testing that method of finding C.M works properly
165     """
166     import skimage.color
167     #img = imread("bilde5.png")
168     img = imread("frame_inv2.png")
169     bwImg = skimage.color.rgb2gray(img)
170     plt.subplot(211)
171     plt.imshow(bwImg, cmap=plt.get_cmap('gray'))
172
173     props = regionprops(label_image=bwImg.astype(int))
174     cm = props[0].centroid
175
176     plt.subplot(212)
177     plt.imshow(img)
178     plt.plot(cm[1], cm[0], "ro",
179             label="Center of mass = (%i, %i)" % (cm[1], cm[0]))
180     plt.legend()
181     plt.show()
182
183
184
185
186 if __name__ == "__main__":
187
188     def readlabdat(filename):
189         """
190         Used to read the file which stores the parameters of the
191         sphere
192         """
193         vids = []; mass = []; radius = []; temp = []
194
195         file = open(filename, "r")
196         for line in file:
197             cols = line.split()
198             mass.append(cols[1])
199             radius.append(cols[2])
200             temp.append(cols[-2])
201             vids.append(cols[-1])
202         file.close()
203

```

```

204         return mass, radius, temp, vids
205     mass, radius, temp, vids = readlabdat("data/labdata.dat")
206
207     folderPath = "/home/nick/Videos/fys2150drag"
208
209     rows = [7, 8, 9, 10]
210
211     outfile = open("data/B_results.dat", "w")
212
213     for row in rows:
214         cm, validFrames = trackCircle(filename=str(vids[row]),
215                                     path=folderPath,
216                                     hMin=67, hMax=216)
217
218         if len(cm[:, 1]) != len(validFrames):
219             print "Tracking interrupted in some frames,"
220             print "Only returning uninterrupted frames."
221             x = []
222             y = []
223             for validFrame in validFrames:
224                 x.append(cm[validFrame, 1])
225                 y.append(cm[validFrame, 0])
226             x = np.array(x).astype(int)
227             y = np.array(y).astype(int)
228         else:
229             x = cm[validFrames[0]:validFrames[-1], 1]
230             y = cm[validFrames[0]:validFrames[-1], 0]
231
232         x = np.array(x)
233         y = np.array(y)
234         validFrames = np.array(validFrames)
235
236         print "Find start/stop of terminal velocity (straight, steep line)
237         to perform linfit:"
238         plt.subplot(211)
239         plt.plot(validFrames, x, "o")
240         plt.xlabel("Frame")
241         plt.ylabel("x-position of center of mass [px]")
242         plt.title("Use to determine start/stop frame of linfit")
243         plt.subplot(212)
244         plt.plot(np.diff(x))
245         plt.show()
246
247         start = int(input("Start index:"))
248         stop = int(input("Stop index:"))
249
250         m, c, dm, dc = fys.linfit(validFrames[start:stop], x[start:stop])
251
252         plt.subplot(211)
253         plt.plot(validFrames, x, ".", label="Position of CM")
254         plt.plot(validFrames[start:stop],
255                 validFrames[start:stop] * m + c,
256                 label="linear fit, y=mx+c")

```



```

256     plt.text(0, 1000, "m = %i [px/frame]\n dm = %i [px/frame]" % (m, dm
257 ))
258     plt.xlabel("Frame")
259     plt.ylabel("x-pos [px]")
260     plt.legend()
261     plt.subplot(212)
262     plt.plot(validFrames, y, ".", label="Position of CM")
263     plt.xlabel("Frame")
264     plt.ylabel("y-pos [px]")
265     plt.savefig("figs/graphs/%s_2.png"%vids[row][: -4])
266     plt.show()
267
268     outfile.write(vids[row] + " & " + "%i"%(m) + " & " + "%i"%dm + "&"
269 + "%s"%mass[row] + "&" + "%s"%radius[row] + "\\ \n")
270
271     # More plots
272
273     outfile.close()

```

scripts/data/labdata.dat

	Type	Mass [g]	Diameter [mm]	FPS	T[C]	Filename
1	Metal	502.76	48.98	100	22.7	A1.avi
2	Metal	28.13	19.02	100	22.8	A2.avi
3	Metal	6.99	11.97	100	22.6	A3.avi
4	Metal	2.08	7.99	100	22.6	A4.avi
5	Metal	0.68	5.48	100	22.5	A5.avi
6	Metal	0.10	2.98	100	22.6	A6.avi
7	Plastic	488.41	99.4	100	22.5	B1.avi
8	Plastic	61.56	50.02	100	22.5	B2.avi
9	Plastic	7.12	23.89	100	22.6	B3.avi
10	Plastic	0.87	12.06	100	22.6	B4.avi
11	White	29.74	25.24	100	22.6	C1.avi
12	BigBlack	31.42	21.08	100	22.5	C4.avi
13	SmallBlack	5.67	16.45	100	22.5	C5.avi
14	BigGreen	31.60	21.86	100	22.4	C3.avi
15	SmallGreen	5.60	16.38	100	22.3	C6.avi
16	BigRed	18.44	24.01	100	22.3	C2.avi
17	Glass	0.27	5.81	100	22.3	C7.avi
18	Small 1	4.1e-3	1.0	100	23.7	D1.avi
19	Small 2	12.0e-3	1.59	100	23.7	D2.avi
20						